


Your Float™ Table is engineered for easy assembly. Carefully follow this procedure to prevent any damage.


Placement and Maintenance

Float™ Tables are designed for indoor use on level floors. Clean glass with glass cleaner; steel parts and wood top with a moist cloth.

NOTE: This instruction sheet is intended for the entire Float™ Table collection; model 2601G is shown for illustration.



www.bdiusa.com
customerservice@bdiusa.com



Step 1

Unpack and identify the parts shown. The assembly workspace should be a clean non-marring surface such as carpet. For missing hardware pieces, please contact BDI Customer Service at: customerservice@bdiusa.com For all other concerns please contact your local BDI Retailer.

Step 2

Lay Top **(A)** so that the pre-installed Pucks **(B)** are facing up.

Step 3

After threading Leveler Glides **(E)** into Steel Legs **(C)**, attach Steel Legs **(C)** to Pucks **(B)** using Screw **(D)** and Hex Wrench **(F)**.

Step 4

Adjust the Leveler Glides **(E)** to level table as needed.